



# Energy saving functions for Canon multifunctional devices (MFDs)


❶ Select the “additional functions” button to change the timer settings.




❷ Select the “Timer Settings”




**3 Select “Auto Sleep Time”**



**4 Adjust the “sleep time”. The recommended sleep time for black and white is after about 20 minutes and for colour is 40 minutes. You should select the time that fits to your convenience.**



4 Adjust as well the “Low-Power Mode”



Thank you!